

Kozy-World®

KOZY-WORLD SUPPORT LEGS

MODEL # 20-5345

Installation of Support Legs


(Cannot be used for garage and ice-house applications)

NOTE: This accessory is required for safe operation when heater is floor mounted.

Before installing Support Legs to heater base, please make sure you have the following items:




Support Leg Screw
(M4*15) x 4



Support Leg x 2

If any part is missing or damaged, do not attempt to assemble the product. Contact our Technical Service Department at 1-814-643-1775 for replacement parts.

1. Set down a blanket onto the table where the heater will be placed for leg installation to prevent scratching of the table and/or the heater.
2. Set back of heater on table with the bottom of heater extending outside the table edge.
3. Fasten Support Legs to heater using Support Leg Screws.



WARRANTY

This product includes a warranty against any defect in materials and workmanship for a period of one (1) year from the date of retail sale. Contact our Consumer Warranty Dept. for more information (800) 776-9425.

To be used with all Kozy-World
Wall-Heater Models:

KWD154	KWN523
KWD215	KWNB241
KWD258	KWNB317
KWD325	KWNB365
KWD378	KWNB537
KWD525	KWP150
KWDB250	KWP212
KWDB320	KWP214
KWDB370	KWP254
KWDB540	KWP352
KWG362	KWP376
KWN149	KWP392
KWN211	KWP396
KWN213	KWP522
KWN253	KWP524
KWN351	KWPB242
KWN375	KWPB318
KWN391	KWPB366
KWN395	KWPB538
KWN521	