




OPERATING INSTRUCTIONS

FRONT VIEW



BACK VIEW



POWER LIGHT: Red light indicates that the unit is on.

HEAT: The fan and the disc heating elements are in use.

FAN: The fan circulates room air only; the heating elements are not in use.

OFF: The DiscFurnace is turned off.

AUTO: The unit operates automatically at the selected temperature.

MAN: The unit must be operated manually by the user.