

## REPLACEMENT PARTS LIST - ALL MODELS

For replacement parts, please call customer service at 1-800-776-9425, 8:30 a.m. –5:00 p.m. EST, Monday – Friday.

| PART | DESCRIPTION     | PART #         |
|------|-----------------|----------------|
| 1    | Back panel      | EFES323001ST   |
| 2    | Screen          | EFEST332T001ST |
| 3    | Flame panel     | EFEST332T002ST |
| 4    | Logset          | EFEST332T003ST |
| 5    | Top panel       | EFES323005ST   |
| 6    | Cabinet panel   | EFEST332T004ST |
| 7    | Bottom panel    | EFES323007ST   |
| 8    | Access panel    | EFES323008ST   |
| 9    | Flame reflector | EFEST332T005ST |
| 10   | Door glass      | EFEST333T001ST |
| 11   | Door            | EFEST333T002ST |
| 12   | Side glass      | EFEST332T008ST |

| PART | DESCRIPTION            | PART #         |
|------|------------------------|----------------|
| 13   | Handle                 | EFES322005ST   |
| 14   | Rivet                  | EFES323013ST   |
| 15   | Leg (Design 3)         | EFEST333T003ST |
| 16   | Fan heater box         | EFES323015ST   |
| 17   | Light barrier panel    | EFEST332T018ST |
| 18   | Control panel switch   | EFES323017ST   |
| 19   | Thermostat             | EFES322006ST   |
| 20   | Power cord & connector | EFES323018ST   |
| 21   | Fan heater             | EFES322007ST   |
| 22   | Motor                  | EFES323020ST   |
| 23   | Lamp socket & bracket  | EFES323021ST   |

*Some parts and specifications may change without notice.*

